



POLYMER BUILT UP ROOFING

NOTES:

1. THE USE OF A METAL SUMP IS NOT RECOMMENDED. HOWEVER, IF USED, CUT INSULATION TO FIT SUMP AND PROCEED AS ABOVE.

**ADUREL
POLYMER
ROOFING SYSTEMS**

ROOF DRAIN

ARD-1